www.thebioflame.com

User's manual and safety instructions of the Bio Flame Fireplace

Keep this user's manual carefully for the life of this product. This product is only to be sold in combination with this user's manual.

Please read the below instrustions before putting you're The Bio Flame to use. Make sure that the guidelines as provided are followed.

The Bio Flame is meant for indoor/outdoor use.
The recommended temperature radius: 10 °C / 50 °F until 25 °C / 77°F

Installation of the wall mount series:

- The Bio Flame is to be placed or hung on a fireproof foundation or wall.
- When attaching to a wall, we advise you to keep a safety distance of 1 cm from the wall.
- Never remove the isolation layer on the backside.
- Make sure that The Bio Flame is leveled, when placed/hung horizontally as well as vertically. This is to make sure that the liquid cannot run out of the burner.
- Keep a safety distance of at least 1 meter (on both the left-, right- and front side) for objects. Keep Flammable objects (e.g. curtains, furniture or bookshelves) away from The Bio Flame.
- Use The Bio Flame only in a draft-free room; otherwise the soot can come into being. However, make sure that there is some form of ventilation.
- The Bio Flame delivers its own unique fuel: The Bio Flame bio ethanol. The Bio Flame can only function optimally in the combination with this bio ethanol. Never use another liquid or gel to refill The Bio Flame. As a consequence, the warranty will expire as well.

Installation of floor level The Bio Flame Fireplaces:

- Make sure Bio Flame is kept at least 20 inches away from furniture and other obstructions.
- Keep pets and small children away from the Bio Flame when operating.

Installation of a recessed firebox:

- The Bio Flame firebox is to be recessed into a non-combustible cavity, preferable concrete board.
- Make sure that The Bio Flame is leveled, when placed/hung horizontally as well as vertically. This is to make sure that the liquid cannot run out of the burner.
- Keep a safety distance of at least 1 meter (on both the left-, right- and front side) for objects. Keep Flammable objects (e.g. curtains, furniture or bookshelves) away from The Bio Flame.
- Do not place The Bio Flame next to, underneath, or on top of a windowsill.
- Use The Bio Flame only in a draft-free room; otherwise the soot can come into being. However, make sure that there is some form of ventilation.
- The Bio Flame delivers its own unique fuel: The Bio Flame bio ethanol. The Bio Flame can only function optimally in the combination with this bio ethanol. Never use another liquid or gel to refill The Bio Flame. As a consequence, the warranty will expire as well.
-

Filling The Bio Flame with The Bio Flame bio ethanol

- Use The Bio Flame bio ethanol ONLY to fill The Bio Flame.
- It is of great importance that the liquid never runs outside the filling opening. Make sure to fill The Bio Flame carefully and slowly, so it cannot be overfilled.

How to fill the Bio Flame

- Place the enclosed funnel in the filling-open.
- Carefully pour The Bio Flame bio ethanol in the funnel. Keep on filling the burner until the liquid remains visible in the filling-opening.
- Warning: Make sure that the liquid does not flow outside the filling-opening, make sure this is dried up before lighting the fire. There should never be fire outside the fire-opening. This is dangerous and can also cause the insert to de-shape and damage the paint on the insert.
- Fill no more than 2/3 of the way to prevent overflow.
- When The Bio Flame is filled, remove the funnel.
- The Bio Flame is ready to be used.